

MIAMI NINE DEPARTURE
(MIA9.MIA) 19MAY22

MIAMI, FLORIDA
MIAMI-OPA LOCKA EXEC (OPT)
MIAMI, FLORIDA

RADAR and DME required.

**TOP ALTITUDE:
ASSIGNED BY ATC**

MIAMI DEP CON
119.45 290.325
(ALTNN, BEECH, BNGOS, DORRL,
FLMGO, FOLZZ, HURCN, ZFP)
125.5 354.1
(GWAVA, KETLL, MAYNR)
ATIS
125.9
CLNC DEL
119.2
GND CON
120.025
OPA LOCKA TOWER*
134.675 (CTAF)

LEE COUNTY
114.15 RSW
Chan 88 (Y)

PALM BEACH
115.7 PBI
Chan 104

FORT LAUDERDALE
114.4 FL
Chan 91

FREEPORT
113.2 ZFP
Chan 79

BIMINI
116.7 ZBV
Chan 114

VIRGINIA KEY
117.1 VKZ
Chan 118

DOLPHIN
113.9 DHP
Chan 86

SPECIAL INSTRUCTIONS
Unless otherwise assigned,
use departure frequency
depicted associated with
the transition in clearance.

NOTE: Turboprops operate in a manner
that will result in best forward
speed and climb rate.

NOTE: File DP in remarks section of
flight plan.


NOTE: Chart not to scale.

(CONTINUED ON FOLLOWING PAGE)

(MIA9.MIA) 24081
MIAMI NINE DEPARTURE

AL-256 (FAA)

MIAMI-OPA LOCKA EXEC (OPT)
MIAMI, FLORIDA



TAKEOFF MINIMUMS
Rwys 9L/R, 12, 27L/R, 30: Standard.



DEPARTURE ROUTE DESCRIPTION

- TAKEOFF RUNWAY 9L:

Climb on heading 093° to 1100 before turning north, thence...
- TAKEOFF RUNWAY 9R:

Climb on heading 093° to 1000 before turning north, thence...
- TAKEOFF RUNWAY 12:

Climb on heading 128° to 600 before turning north, thence...
- TAKEOFF RUNWAY 27L:

Climb on heading 273° thence...
- TAKEOFF RUNWAY 27R:

Climb on heading 273° to 500 before turning north, thence...
- TAKEOFF RUNWAY 30:

Climb on heading 308° thence...

... maintain 2000 or assigned higher altitude for RADAR vectors to appropriate transition.
Expect further clearance to filed altitude ten (10) minutes after departure.

- ALTNN TRANSITION (MIA9.ALTNN):

From over FLL VOR/DME on FLL R-358 to ALTNN.
- BEECH TRANSITION (MIA9.BEECH):

From over FLL VOR/DME on FLL R-104 to BEECH.
- BNGOS TRANSITION (MIA9.BNGOS):

From over DHP VORTAC on DHP R-321 to BNGOS.
- DORRL TRANSITION (MIA9.DORRL):

From over DHP VORTAC on DHP R-003 to DORRL.
- FLMGO TRANSITION (MIA9.FLMGO):

From over DHP VORTAC on DHP R-348 to FLMGO.
- FOLZZ TRANSITION (MIA9.FOLZZ):

From over DHP VORTAC on DHP R-065 to FOLZZ.
- FREEPORT TRANSITION (MIA9.ZFP):

From over DHP VORTAC on DHP R-065 to FOLZZ then on ZFP R-249 to ZFP VOR/DME.
- GWAVA TRANSITION (MIA9.GWAVA):

From over DHP VORTAC on DHP R-151 to GWAVA.
- HURCN TRANSITION (MIA9.HURCN):

From over DHP VORTAC on DHP R-332 to HURCN.
- KETLL TRANSITION (MIA9.KETLL):

From over VKZ VOR/DME on VKZ R-114 to KETLL.
- MAYNR TRANSITION (MIA9.MAYNR):

From over DHP VORTAC on DHP R-196 to MAYNR.