

ILS Z RWY 16R
VAN NUYS (VNY)

MALSR


MISSED APPROACH: Climb to cross VNY 1.5 DME south of VNY VOR/DME at or below 1750 then climbing left turn to 4600 on VNY VOR/DME R-152 to HIRV/VNY VOR/DME 8 DME, direct SMO VOR/DME then on SMO VOR/DME R-267 then on VTU VOR/DME R-087 to VTU VOR/DME and hold.

A descent to at or below 1750 may be required when executing an early missed approach.

HIRL Rwy 16R-34L **L**
MIRL Rwy 16L-34R