

LOC/DME I-FWA	APP CRS	Rwy Idg	8001
109.9	321°	TDZE	800
Chan 36		Apt Elev	815

ILS or LOC RWY 32

FORT WAYNE INTL (FWA)

DME required for LOC only. DME or RADAR required for procedure entry.			MALSR		MISSED APPROACH: Climb to 3000 then left turn on FWA VORTAC R-285 to TELEY INT/FWA 17.5 DME and hold.		
For inop ALS, increase S-ILS 32 Cat E visibility to RVR 4000, S-LOC 32 Cat E visibility to RVR 6000. Use I-FWA DME when on the localizer course. # RVR 1800 authorized with use of FD or AP or HUD to DA.							
ASR							
ATIS 121.25 360.825		FORT WAYNE APP CON 127.2 284.6		FORT WAYNE TOWER 119.1 269.325		GND CON 121.9 348.6	CLNC DEL 124.75

