


VOR or TACAN RWY 14
FORT WAYNE INTL (FWA)

MISSED APPROACH: Climb to 3000 on FWA R-134 to OSBER INT/FWA 22 DME and hold.

CLNC DEL
124.75

One Minute Holding Pattern			KABDE FWA [12] RADAR		WAINE FWA [5.9] RADAR		3000 ↑ FWA R-134		OSBER △	
10000 ← 325° 3000 → 145°			145°		2400		FWA [2.5]		NOYIS FWA [1.6]	
			6.1 NM		3.4 NM		0.9		0.5	
			3.05° TCH 53							
CATEGORY	A	B	C	D	E					
S-14	1280-1	478 (500-1)	1280-1 $\frac{3}{8}$ 478 (500-1 $\frac{3}{8}$)	1280-1 $\frac{1}{2}$ 478 (500-1 $\frac{1}{2}$)	1280-1 $\frac{1}{4}$ 478 (500-1 $\frac{1}{4}$)					
C CIRCLING	1300-1	485 (500-1)	1360-1 $\frac{1}{2}$ 545 (600-1 $\frac{1}{2}$)	1520-2 $\frac{1}{4}$ 705 (800-2 $\frac{1}{4}$)	1520-2 $\frac{1}{2}$ 705 (800-2 $\frac{1}{2}$)					