

ILS RWY 9 (CAT II & III)
NEW YORK STEWART INTL (SWF)

MISSED APPROACH: Climb to 1200 then climbing left turn to 3000 direct IGN VOR/DME and hold.

Procedure NA for arrivals at SAX
VORTAC on airway radials 029 CW 060.

SPARTA
115.7 SAX
Chan 104

One Minute Holding Pattern

SW LOM
2096

2300 ← 272°
092° →

GS 3.00°
TCH 60'

2100

092°

1200 3000 IGN

VGSi and ILS glidepath not coincident
(VGSi Angle 3.00/TCH 65').

CATEGORY	A	B	C	D
S-ILS 9		CAT II RA 97/12	100	DA 582
S-ILS 9		CAT IIIa RVR 07		
S-ILS 9		CAT IIIb RVR 06		
S-ILS 9		CAT IIIc NA		

CATEGORY II & III ILS SPECIAL AIRCREW & AIRCRAFT CERTIFICATION REQUIRED

TDZ/CL Rwy 9
HIRL Rwy 9-27 and 16-34
REIL Rwy 16, 27 and 34