

LOC/DME I-FWA 109.9 Chan 36	APP CRS 321°	Rwy Idg TDZE Apt Elev 8001 800 815	ILS or LOC RWY 32 FORT WAYNE INTL (FWA)
---	------------------------	--	--

DME required for LOC only. DME or RADAR required for procedure entry.			MALSR 		MISSED APPROACH: Climb to 3000 then left turn on FWA VORTAC R-285 to TELEY INT/FWA 17.5 DME and hold.
 For inop ALS, increase S-ILS 32 Cat E visibility to RVR 4000, S-LOC 32 Cat E visibility to RVR 6000. Use I-FWA DME when on the localizer course. # RVR 1800 authorized with use of FD or AP or HUD to DA.					
ATIS 					