

ILS Z or LOC Z RWY 19
RUTLAND/SOUTHERN VERMONT RGNL (RUT)

MAILED



MISSED APPROACH: Climb to 1900 then climbing right turn to 5700 on heading 360° and CAM VOR/DME R-033 to KOPVE/I-RUT 16.31 DME and hold. If unable to meet climb gradient, see ILS Y or LOC Y Rwy 19. # Missed approach requires minimum climb of 425 feet per NM to 3200.

UN|COM
122.8 (CTAF) **L**