

VOR/DME SCB 111.0 Chan 47	APP CRS 341°	Rwy Idg 4200 TDZE 1319 Apt Elev 1325
---	------------------------	---

VOR/DME RWY 35
SCRIBNER STATE (SCB)

T
A NA

Use Fremont altimeter setting.

MISSED APPROACH: Climb to 3000 then right turn direct SCB VOR/DME and hold.

FET AWOS-3 121.275	OMAHA APP CON 120.1 354.05	CTAF 122.9
------------------------------	--------------------------------------	----------------------

