

ILS or LOC RWY 17R
OKC WILL ROGERS INTL (OKC)

MISSED APPROACH: Climb to 2000 then climbing right turn to 3000 on heading 311° and on PWA VOR/DME R-216 to JESKE INT/PWA 14.5 DME and hold.

CATEGORY	A	B	C	D	E
S-ILS 17R*	1482/24		200 (200-½)		
S-LOC 17R	1800/24	518 (600-½)	1800/55 518 (600-1)		
CIRCLING	1800-1	504 (600-1)	1960-1¾ 664 (700-1¾)	2000-2¼ 704 (800-2¼)	2240-3 944 (1000-3)
COTOX FIX MINIMUMS					
S-LOC 17R	1620/24	338 (400-½)	1620/26 338 (400-½)		
CIRCLING	1740-1 444 (500-1)	1760-1 464 (500-1)	1960-1¾ 664 (700-1¾)	2000-2¼ 704 (800-2¼)	2240-3 944 (1000-3)