

LOC I-SAC 110.3	APP CRS 019°	Rwy Ldg 5503 TDZE 21 Apt Elev 24
---------------------------	------------------------	---

ILS or LOC RWY 2

SACRAMENTO EXEC (SAC)

▼

▲

When local altimeter setting not received, use Sacramento Intl altimeter setting and increase DA to 322 feet, increase all MDAs 40 feet and Circling Cat D visibility ¼ SM. Autopilot coupled approach NA below 335 feet. For inop MALSRR, increase S-ILS 2 all Cats visibility to ¾ SM and S-LOC 2 Cat C/D visibility to 1 SM. For inop MALSRR when using Sacramento Intl altimeter setting, increase S-ILS 2 all Cats visibility to ¾ SM.

MALSRR

MISSED APPROACH:
Climb to 600 then climbing left turn to 1600 direct SAC VORTAC and hold.

ATIS 118.075	NORCAL APP CON 125.25 257.9	EXEC TOWER★ 119.5 (CTAF) 0 278.8	GND CON 125.0	UNICOM 122.95
------------------------	---------------------------------------	--	-------------------------	-------------------------

