

ILS or LOC RWY 23

MISSED APPROACH: Climb to 1400 then climbing left turn to 2600 direct MZZ VOR/DME and hold.



UNICOM
123.0 (CTAF) **L**



CATEGORY	A	B	C	D
S-ILS 23	1027-1/2 200 (200-1/2)			
S-LOC 23	1300-1/2 473 (500-1/2)	1300-1 473 (500-1)		
 CIRCLING	1300-1 468 (500-1)	1400-1 1/2 568 (600-1 1/2)		1420-2 588 (600-2)
ZUVEL FIX MINIMUMS* (DUAL VOR RECEIVERS or DME REQUIRED)				
S-LOC 23	1220-1/2 393 (400-1/2)	1220-5/8 393 (400-5/8)		
 CIRCLING	1260-1 428 (500-1)	1300-1 468 (500-1)	1400-1 1/2 568 (600-1 1/2)	1420-2 588 (600-2)

KOKOMO MUNI (OKK)
ILS or LOC RWY 23