

ILS or LOC RWY 16

	MALS R
	MISSED APPROACH: Climb to 1000 then climbing right turn to 3000 on heading 020° and on ONP VORTAC R-343 to BUHRS/ONP 6.6 DME and hold, continue climb-in-hold to 3000.

REIL Rwy 34 **L**
MIRL Rwy 2-20 **L**
HIRL Rwy 16-34 **L**