

LOC/DME I-RUT 111.7 Chan 54	APP CRS 194°	Rwy Ldg 5004 TDZE 787 Apt Elev 787
---	------------------------	---

ILS Y or LOC Y RWY 19
RUTLAND/SOUTHERN VERMONT RGNL (RUT)

DME required.



MALSR



MISSED APPROACH: Climb to 2840 then climbing right turn to 5700 on heading 360° and CAM VOR/DME R-033 to KOPVE/I-RUT 16.3 DME and hold.

AWOS-3PT
118.375

BOSTON CENTER
135.7 282.2

UNICOM
122.8 (CTAF) **L**