

VOR or TACAN RWY 36
TALLAHASSEE INTL (TLH)

MALSR
A5

MISSED APPROACH: Climb to 4000 direct SZW VORTAC and on SZW VORTAC R-288 to QUILL/SZW 11.8 DME and hold, continue climb-in-hold to 4000.

MISSED APCH FIX

QUILL
SZW [11.8]
108°
117.5 SZW
R-288
Chan 122

R-288

SEMINOLE
117.5 SZW [11.8]
Chan 122

3000 to HAKUT
173° (21)

Λ1048
Δ686
Δ845
Δ267
Δ323
Δ549
Δ476

406Λ

215±Λ
209±Λ
XBEGN
SZW [11.8]

DACAR
SZW [14.5]

1600
353°
(6.5)

(IF/IAF)
HAKUT
SZW [21]

173°
1 min
353°

HOLD 6000
3000

ELEV 83 TDZE 62

TDZ/CL Rwy 27
REIL Rwys 9 and 18
HIRL Rwys 9-27 and 18-36

MSA SZW 25 NM
3300

4000 ↑	SZW ⬡	SZW R-288	QUILL △					
CATEGORY	A		B		C		D	E
S-36	460/24		398 (400-½)		460/35		398 (400-¾)	
C CIRCLING	580-1 497 (500-1)	600-1 517 (600-1)	640-1½ 557 (600-1½)	800-2¼ 717 (800-2¼)	1000-3 917 (1000-3)			