

SOCAL APP CON
1124.35 279.625
KNZY ATIS ★
317.8
SDM ATIS
132.35

ARRIVAL ROUTE DESCRIPTION

IMPERIAL TRANSITION (IPL.CHASR2)
MOMAR TRANSITION (MOMAR.CHASR2)
PARKER TRANSITION (PKE.CHASR2)
TRUE TRANSITION (TRUE.CHASR2)

NZY/SDM: From TOPGN on track 249° to cross CHASR at 6400, then on track 250°. Expect RADAR vectors to final approach course.

NOTE: RADAR required.

NOTE: RNAV 1.


NOTE: DME/DME/IRU or GPS required.

NOTE: Turbojet and turboprop aircraft only.

NOTE: Descend via mach number until intercepting

270K. Maintain 270K until slowed by the

STAR or assigned by ATC.



NOTE: Chart not to scale.