

VOR RWY 13
COLUMBIA RGNL (COU)

MISSED APPROACH: Climb to 1900 then climbing right turn to 2700 on COU VOR/DME R-333 to SAPPY INT/COU 6 DME and hold.

MSA COU 25 NM
3100

IAF HALLSVILLE
114.2 HLV
Chan 89

Procedure NA for arrival on HLV VORTAC
airway radials 177 CW 203.

2900 NoPT
226°
[12.2]

R-333
R-226
2700
153° (6)

(IF)
ANNOT INT
COU [12]

HOLD
10000
2700

153°
1 min
333°

(IAF)
SAPPY INT
COU [6]

BATYE INT
COU [3.8]

985 A

2700 to SAPPY
333° (6)

COACT
COU [1.1]

COLUMBIA
110.2 COU
Chan 39

2700 to VOR/DME
349° (13.2)

BNTON

ELEV 889 D TDZE 888

One Minute Holding Pattern

SAPPY INT COU 6

BATYE INT COU 3.8

COU R-333

COU COACT 1.1

COU VOR/DME

10000 ← 333°

2700 ← 153°

3.31° TCH 45

1880

2.2 NM

1.9 NM

0.8

0.2

ELEV 889

D TDZE 888

153°

31

20

100 X 130

740 X 130

TWR

HIRL Rwy 2-20

MIRL Rwy 13-31

REIL Rwy 20

REIL Rwy 13 and 31

FAF to MAP 4.9 NM

Knots	60	90	120	150	180
Min:Sec	4:54	3:16	2:27	1:58	1:38