

DALLAS-FORT WORTH INTL (DFW)
DALLAS-FORT WORTH, TEXAS

MAVERICK
113.1 TTT 
Chan 78

NOTE: PODDE Transition: ATC assigned.
NOTE: Maintain 240K until leaving 5000.
NOTE: PROPS: Expect COYOTE or KINGDOM DEPARTURE.

NOTE: Chart not to scale.

WICHITA FALLS
112.7 SPS :::-.
Chan 74

CHILDRESS
117.0 CDS 
Chan 117

9

LUBBOCK
109.2 LBB 
Chan 29

PANHANDLE
116.6 PNH
Chan 113

CORONA
115.5 CNX 
Chan 102

ABILENE
113.7 ABI 
Chap 84

MILLSAP
117.7 MQP 
Chap 124

Rwys 13L/R, 17L/C/R, 18L/R, 31L/R, 35L/C, 36L/R: Standard.
Rwy 35R: Standard with minimum climb of 245'/NM to 1200.

(CONTINUED ON FOLLOWING PAGE

DALLAS-FORT WORTH, TEXAS
DALLAS-FORT WORTH INTL (DFW)

(WORTH1.TTT) 25JAN24

T	DEPARTURE ROUTE DESCRIPTION TAKEOFF RUNWAYS 13L/R, 17L/C/R, 35L/C/R: Climb on assigned heading thence. . . . TAKEOFF RUNWAYS 18L/R: Climb on heading 190°, thence. . . . TAKEOFF RUNWAYS 36L/R: Climb on heading 340°, thence.for RADAR vectors to appropriate route, maintain 10000 and expect filed altitude 10 minutes after departure. TAKEOFF RUNWAYS 31L/R: Climb on assigned heading and altitude, thence.for RADAR vectors to appropriate route, maintain 5000 and expect filed altitude 10 minutes after departure. ABILENE TRANSITION (WORTH1.ABI): From over TTT VOR/DME on TTT R-250 to PODDE, then on MQP R-081 to MQP VORTAC, then on MQP R-253 and ABI R-071 to ABI VORTAC. CHILDRESS TRANSITION (WORTH1.CDS): From over TTT VOR/DME on TTT R-285 to SCABI, then on CDS R-127 to CDS VORTAC. CORONA TRANSITION (WORTH1.CNX): From over TTT VOR/DME on TTT R-250 to PODDE, then on MQP R-081 to MQP VORTAC, then on MQP R-253 and ABI R-071 to ABI VORTAC, then on ABI R-296 and LBB R-114 to LBB VORTAC, then on LBB R-272 and CNX R-088 to CNX VORTAC. LUBBOCK TRANSITION (WORTH1.LBB): From over TTT VOR/DME on TTT R-250 to PODDE, then on MQP R-081 to MQP VORTAC, then on MQP R-253 and ABI R-071 to ABI VORTAC, then on ABI R-296 and LBB R-114 to LBB VORTAC. PANHANDLE TRANSITION (WORTH1.PNH): From over TTT VOR/DME on TTT R-285 to SCABI, then on CDS R-127 to CDS VORTAC, then on CDS R-297 and PNH R-118 to PNH VORTAC. PODDE TRANSITION (WORTH1.PODDE): From over TTT VOR/DME on TTT R-250 to PODDE. TEXICO TRANSITION (WORTH1.TXO): From over TTT VOR/DME on TTT R-250 to PODDE, then on MQP R-081 to MQP VORTAC, then on MQP R-253 and ABI R-071 to ABI VORTAC, then on ABI R-296 and LBB R-114 to LBB VORTAC, then on LBB R-305 and TXO R-124 to TXO VORTAC.
-------------------------	---