

FRESNO APP CON
132.35 268.7
ATIS
121.35 273.6

AL-162 (FAA)

FRIANT
115.6 FRA
Chan 103

LOCALIZER 111.3
I-RPW
Chan 50

LOCALIZER 111.3
I-FAT
Chan 50

PANOCHÉ
112.6 PXN
Chan 73

TULE
116.25 TTE
Chan 109(Y)

NOTE: Chart not to scale.

ARRIVAL ROUTE DESCRIPTION

From over TULE (TTE) VOR/DME on TTE R-323 and FRIANT (FRA) VORTAC R-142 to ALTTA. Expect ILS or LOC RWY 29R approach. For Rwy 11L operations: Depart ALTTA heading 310° and expect RADAR vectors to LOC Y RWY 11L.

LOST COMMUNICATIONS: Rwy 11L: Proceed to FRA VORTAC on V459, then on V230, execute the LOC Y RWY 11L approach.