

VANDENBERG THREE DEPARTURE (VBG3.MQO)

ATIS
 133.125 257.975
 GND CON
 121.75 275.8
 CLNC DEL
 121.75 275.8
 VANDENBERG TOWER ★
 124.95 326.2
 SANTA BARBARA DEP CON ★
 124.15 327.8

[USSF]

Rwy	Knots	60	120	180	240	300	360
30	V/V(fpm)	280	560	840	1120	1400	1680

Minimum Climb Rate to 700

4000



MORRO BAY
 112.4 MQO
 Chan 71

334°

1300

R-154

305°

447

VANDENBERG
 Chan 59(Y) VBG
 1377

Use extreme caution for extensive UAS ops in the vicinity



DEPARTURE ROUTE DESCRIPTION

TAKEOFF RWY 30: Climb on track 305° to intercept MQO VORTAC R-154 at or above 1300 direct to MQO. Cross MQO at or above 4000. Expect vectors to first filed fix/route prior to MQO.