

LOC/DME BC RWY 10
NOME (OME) (PAOM)

MISSED APPROACH: Climb to 3000
direct OME VOR/DME and hold,
continue climb-in-hold to 3000.

NOME (OME) (PAOM)
LOC/DME BC RWY 10