

VORTAC FWA
117.8
Chan **125**

APP CRS
145°

Rwy Ldg
TDZE
Apt Elev
8001
802
815

VOR or TACAN RWY 14
FORT WAYNE INTL (FWA)

DME required.

▼

▲

ASR

MISSED APPROACH: Climb to 3000 on FWA R-134 to OSBER/FWA 22 DME and hold.

ATIS
121.25 360.825

FORT WAYNE APP CON
127.2 284.6

FORT WAYNE TOWER
119.1 269.325

GND CON
121.9 348.6

