

VORTAC BRO	APP CRS	Rwy Ldg	7257
116.3	311°	TDZE	36
Chan 110		Apt Elev	36

VOR Y or TACAN RWY 31

VALLEY INTL (HRL)

DME required.

When local altimeter setting not received, use Port Isabel altimeter setting and increase all MDAs 60 feet.



MISSED APPROACH: Climbing right turn to 2000 on BRO R-311 to ZOCKE/12 DME and hold.

ATIS	VALLEY APP CON	HARLINGEN TOWER ★	GND CON	UNICOM
124.85	120.7 279.5	119.3 (CTAF) 317.6	121.7	122.95

