

LOC I-FXE 111.1	APP CRS 091°	Rwy Ldg TDZE 13 Apt Elev 13
---------------------------	------------------------	---

ILS or LOC RWY 9

FORT LAUDERDALE EXEC (FXE)

⚠


When local altimeter setting not received, use FLL altimeter setting: increase S-ILS 9 DA to 231 feet; increase all MDAs 20 feet.

MALSR

MISSED APPROACH:

Climb to 1000 then climbing left turn to 2100 on heading 285° and on VKZ VOR/DME R-348 to SHANC INT/VKZ 35 DME and hold.

ATIS 119.85	MIAMI APP CON 119.7 306.3	EXECUTIVE TOWER 120.9 239.3	GND CON 121.75
-----------------------	-------------------------------------	---------------------------------------	--------------------------



*500 when using FLL altimeter setting.				
One Minute Holding Pattern				
GS 3.00° TCH 55				
CATEGORY	A	B	C	D
S-ILS 9	213-½ 200 (200-½)			
S-LOC 9*	480-½ 467 (500-½) 480-1 467 (500-1)			
CIRCLING	520-1 507 (600-1)	620-1 607 (700-1)	780-2¼ 767 (800-2¼)	780-2½ 767 (800-2½)
TRUBE FIX MINIMUMS (DUAL VOR RECEIVERS REQUIRED)				
S-LOC 9	360-½ 347 (400-½) 360-¾ 347 (400-¾)			
CIRCLING	520-1 507 (600-1)	620-1 607 (700-1)	780-2¼ 767 (800-2¼)	780-2½ 767 (800-2½)

ELEV 13	TDZE 13
REIL Rwy 13, 27 and 31	
HIRL Rwy 9-27	
MIRL Rwy 13-31	
FAF to MAP 6.1 NM	
Knots	60 90 120 150 180
Min:Sec	6:06 4:04 3:03 2:26 2:02