

VOR RWY 20R
KENAI MUNI (ENA) (PAEN)

MALSR

MISSED APPROACH:
Climb to 2200 on ENA
VOR/DME R-192 to DIXIT/ENA
VOR/DME 10 DME and hold.

DME REQUIRED

MSA ENA 25 NM

2200

3500

030°

210°

090°

(IAF) TWIGI ENA [8]

R-266

KENAI 117.6 ENA Chan 123

252

1000 192° (2.5)

FATEL ENA [2.5]

2000 to TBONE 012° (8)

LR-357

1300 092° (5.5)

LR-027

2000 NoPT ENA [8] Arc

2000 NoPT ENA [8] Arc

(IAF) ROJAR ENA [8]

R-095

DIXIT ENA [10]

192°

012°

192°

min

(IF/IAF) TBONE ENA [8]

R-012

