

LOC I-SAC <u>110.3</u>	APP CRS 019°	Rwy Ldg TDZE Apt Elev	5503 21 24
----------------------------------	------------------------	-----------------------------	---------------------------------------

ILS or LOC RWY 2
SACRAMENTO EXEC (SAC)

T When local altimeter setting not received, use Sacramento Intl altimeter setting and increase DA to 322 feet, increase all MDAs 40 feet and Circling Cat D visibility $\frac{1}{2}$ SM. Autopilot coupled approach NA below 335 feet. For inop MALSR, increase S-ILS 2 all Cats visibility to $\frac{1}{2}$ SM and S-LOC 2 Cat C/D visibility to 1 SM. For inop MALSR when using Sacramento Intl altimeter setting, increase S-ILS 2 all Cats visibility to $\frac{1}{2}$ SM.

MALSR



MISSED APPROACH:

Climb to 600 then climbing
left turn to 1600 direct
SAC VORTAC and hold.

ATIS 118.075	NORCAL APP CON 125.25 257.9	EXEC TOWER ★ 119.5 (CTAF) 0 278.8	GND CON 125.0	UNICOM 122.95
------------------------	---------------------------------------	---	-------------------------	-------------------------

