

|                                               |                        |                                                                 |
|-----------------------------------------------|------------------------|-----------------------------------------------------------------|
| VORTAC SGF<br><b>116.9</b><br>Chan <b>116</b> | APP CRS<br><b>196°</b> | Rwy Ldg <b>7003</b><br>TDZE <b>1262</b><br>Apt Elev <b>1268</b> |
|-----------------------------------------------|------------------------|-----------------------------------------------------------------|

VOR or TACAN RWY 20  
SPRINGFIELD-BRANSON NTL (SGF)

|                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |                                         |                                                                                                          |
|------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------|----------------------------------------------------------------------------------------------------------|
| DME required.          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | MALS<br>$\textcircled{A_4}$ $\equiv$    | MISSED APPROACH: Climb to 3000 then right turn to intercept SGF R-206 to BLUE INT/SGF 21.8 DME and hold. |
| <b>T</b><br><b>NA</b>  | Rwy 20 helicopter visibility reduction below $\frac{3}{4}$ SM NA. For inop ALS, increase S-20 Cat E to $\frac{1}{8}$ SM. VDP NA when using HFJ altimeter setting. When local altimeter setting not received, use HFJ altimeter setting: increase all MDAs 100 feet; increase S-20 visibility Cats C, D and E $\frac{1}{4}$ SM, and Circling visibility Cat C and D $\frac{1}{2}$ SM. For inop ALS, use HFJ altimeter setting: increase S-20 visibility Cats C, D and E to $\frac{1}{4}$ SM. |                                         |                                                                                                          |
| ATIS<br><b>135.125</b> | SPRINGFIELD APP CON<br><b>124.95 290.5</b>                                                                                                                                                                                                                                                                                                                                                                                                                                                  | SPRINGFIELD TOWER<br><b>119.9 257.8</b> | GND CON<br><b>121.9 251.15</b>                                                                           |

