



LOC/DME I-CWT 108.7 Chan 24	APP CRS 356°	Rwy Ldg TDZE Apt Elev	8720 10 11
---	------------------------	-----------------------------	---------------------------------------

ILS or LOC RWY 36

ST PETE-CLEARWATER INTL (PIE)

DME or RADAR required.	MISSED APPROACH: Climb to 600 then climbing left turn to 2000 on PIE VORTAC R-276 to LAFAL INT/PIE 8 DME and hold.
------------------------	--

ATIS 134.5	TAMPA APP CON 125.3 316.05	ST PETERSBURG-CLEARWATER TOWER * 118.3 (CTAF) 0 257.8	GND CON 121.9 348.6	UNICOM 122.95
----------------------	--------------------------------------	---	-------------------------------	-------------------------



600	2000	SAWGA FIX MINIMUMS DME required.			
↑	PIE R-276	SONES			
	LAFAL INT	I-CWT 7.8			
		RADAR			
		One Minute Holding Pattern			
*LOC only.					
	SAWGA I-CWT 3.8	2000			
	*I-CWT 2.6	176° → 2000			
	I-CWT 1.7	356°			
		2000			
		GS 3.00° TCH 55°			
		VGSI and ILS glidepath not coincident (VGSI Angle 3.00/TCH 76).			
	0.9	1.2			
		4 NM			
CATEGORY	A	B	C	D	E
S-ILS 36	210/40 200 (200-¾)				
S-LOC 36	680/55	670 (700-1)	680-178 670 (700-178)		
CIRCLING	680-1	669 (700-1)	680-1½ 669 (700-1½)	680-2 669 (700-2)	960-3 949 (1000-3)
SAWGA FIX MINIMUMS					
S-LOC 36	380/55 370 (400-1)				
CIRCLING	520-1	509 (600-1)	640-1½ 629 (700-1½)	680-2 669 (700-2)	960-3 949 (1000-3)