

VORTAC SZW 117.5 Chan 122	APP CRS 353°	Rwy Ldg TDZE Apt Elev 7000 62 83	VOR or TACAN RWY 36 TALLAHASSEE INTL (TLH)	
---	------------------------	--	---	--

DME required.		MALSR	MISSED APPROACH: Climb to 4000 direct SZW VORTAC and on SZW VORTAC R-288 to QUILL/SZW 11.8 DME and hold, continue climb-in-hold to 4000.
T A For inop ALS, increase VOR Cat E visibility to RVR 6000. For inop ALS, increase TACAN Cat E visibility to RVR 6000.		AS	

ATIS 119.45 239.25	TALLAHASSEE APP CON ★ 135.8 317.4	TALLAHASSEE TOWER ★ 118.7 (CTAF) 0 257.8	GND CON 121.9 348.6	UNICOM 123.075
------------------------------	---	---	-------------------------------	--------------------------

