

VORTAC FWA	APP CRS	Rwy Ldg	8001
117.8	145°	TDZE	802
Chan 125		Apt Elev	815

VOR or TACAN RWY 14
FORT WAYNE INTL (FWA)

DME required.		MISSED APPROACH: Climb to 3000 on FWA R-134 to OSBER/FWA 22 DME and hold.		
ASR				
ATIS 121.25 360.825		FORT WAYNE APP CON 127.2 284.6	FORT WAYNE TOWER 119.1 269.325	GND CON 121.9 348.6

