

ILS or LOC RWY 16
DRAUGHON-MILLER CENTRAL TEXAS RGNL (TPL)

MALSR

MISSED APPROACH: Climb to 1100 then continue climb to 3600 on heading 160° and on ACT VORTAC R-181 to CONRA INT/ACT 40.2 DME and hold, continue climb-in-hold to 3600.

ELEV 682 D TDZE 682

MIRA Rwy 3-21
MIRA Rwy 16-34

FAF to MAP 3 NM

Knots	60	90	120	150	180
Min:Sec	3:00	2:00	1:30	1:12	1:00