

ILS or LOC RWY 16L
PEROT FLD/FORT WORTH ALLIANCE (AFW)

MISSED APPROACH: Climb to 1200 then climbing right turn to 3000 on heading 330° and FUZ VORTAC R-303 to OBLON INT/FUZ 24 DME and hold.


[illegible]

TDZ/CL Rwy's 16L and 34R HIRL Rwy's 16L-34R and 16R-34L REIL Rwy's 16R and 34L					
FAF to MAP 5.1 NM					
Knots	60	90	120	150	180
Min:Sec	5:06	3:24	2:33	2:02	1:42