

AIRPORT DIAGRAM

HILO INTL (ITO) (PHTO)
HILO, HAWAII

ATIS
 126.4
 HILO TOWER★
 118.1 263.1
 GND CON
 121.9

D

VAR 9.5° E

JANUARY 2020
ANNUAL RATE OF CHANGE
0.0° E

-19°44'N

PAC, 16 MAY 2024 to 11 JUL 2024

The diagram illustrates the airport layout with the following details:

- Runway 25:** Dimensions 5600 X 150, ELEV 25, bearing 031.2°.
- Taxiway 28:** Dimensions 9800 X 150, ELEV 37, bearing 260.4°.
- Blast Pads:** Three pads, each 200 X 150, located at ELEV 25, 27, and 37.
- Other Features:** Hangars, Cargo, Fire Station, TWR, CAT, and Terminal.
- Orientation:** 19°43'N latitude.
- Field Elevation:** 38.

PAC, 16 MAY 2024 to 11 JUL 2024

RWY 03-21
PCN 69 F/B/W/T
S-75, D-80, 2D-140, 2D/2D2-410
RWY 08-26
PCN 69 F/B/W/T
S-75, D-250, 2D-350, 2D/2D2-850

19°43'N

-19°42'N

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

155°03'W

283

155°02'W

AIRPORT DIAGRAM

20310

HILO, HAWAII

HILO INTL (ITO) (PHTO)