


AIRPORT DIAGRAM

SARASOTA/BRADENTON INTL (SRQ)

SARASOTA/BRADENTON, FLORIDA



ATIS 124.375
 SARASOTA TOWER★ 120.1 256.8
 GND CON 121.9 273.6
 CLNC DEL 118.25
D

AL-640 (FAA)

↑
 NAV 5.6° N
 JANUARY 2020
 ANNUAL RATE OF CHANGE
 0.1° W

NON-MOVEMENT
 AREA

ELEV 26

ELEV 24

27°24'N

27°23'N

RWY 04-22
 PCN 53 F/A/W/T
 S-120, D-219, 2D-404
 RWY 14-32
 PCN 47 F/A/X/T
 S-118, D-196, 2D-358

U.S. CUSTOMS &
 BORDER PROTECTION
 GA PARKING

ELEV 22

FIELD
 ELEV
 30

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

82°34'W

82°33'W

AIRPORT DIAGRAM

SARASOTA/BRADENTON, FLORIDA

SARASOTA/BRADENTON INTL (SRQ)

SE-3, 19 MAY 2022 to 16 JUN 2022

SE-3, 19 MAY 2022 to 16 JUN 2022