

# AIRPORT DIAGRAM

AL-282 (FAA)

NASHVILLE INTL (BNA)  
NASHVILLE, TENNESSEE

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.  
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.


SAID in use. Operate transponders with altitude reporting mode and ADS-B (if equipped) enabled on all airport surfaces.

D-ATIS 135.1  
NASHVILLE TOWER 118.6 257.8  
GND CON 121.9 348.6  
CLNC DEL 126.05  
CPDLC  
PDC



SE-1, 23 JAN 2025 to 20 FEB 2025

SE-1, 23 JAN 2025 to 20 FEB 2025



# AIRPORT DIAGRAM

NASHVILLE, TENNESSEE  
NASHVILLE INTL (BNA)