

AIRPORT DIAGRAM

AL-61 (FAA)

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

D

25°55'N

81 ELEV
20

HANGA

AIR
FREIGHT
TERMINAL
+
CARGO
FACILITY

FIRE
STATION

ELEV

17
+ +
B
13

FBO

PASSENGER
TERMINAL

FBC

FIELD
ELEV
22

RWY 13-31
PCR 660 F/B/X/T
S-75, D-170, 2D-240
RWY 18-36
PCR 540 F/D/X/T
S-75, D-144, 2D-150

JANUARY 2025
ANNUAL RATE OF CHANGE
0.1° W

 $\text{AR } 3.1^\circ \text{ E}$

ELEV
20

97°26'W

97°25'W

AIRPORT DIAGRAM

25275

BROWNSVILLE, TEXAS

BROWNSVILLE/SOUTH PADRE ISLAND INTL (BRO)

SC-3, 22 JAN 2026 to 19 FEB 2026