

AIRPORT DIAGRAM

TUCSON INTL (TUS)
TUCSON, ARIZONA

D

The diagram is a technical layout of the Tucson International Airport. It shows the following features:

- Runways:** Runway 04-22 (PCR 470 F/A/X/T, S-119, D-209, 2D-393, 2D/2D2-830), Runway 12-30 (PCR 650 R/A/W/T, S-120, D-214, 2D-405, 2D/2D2-918), and Runway 15-36 (PCR 650 R/A/W/T, S-120, D-214, 2D-405, 2D/2D2-918).
- Taxiways:** A1, A2, A3, A4, A5, A6, A7, A8, A9, A10, A11, A12, A13, A14, A15, A16, A17, A18, A19, A20, A21, A22, A23, A24, A25, A26, A27, A28, A29, A30, A31, A32, A33, A34, A35, A36, A37, A38, A39, A40, A41, A42, A43, A44, A45, A46, A47, A48, A49, A50, A51, A52, A53, A54, A55, A56, A57, A58, A59, A60, A61, A62, A63, A64, A65, A66, A67, A68, A69, A70, A71, A72, A73, A74, A75, A76, A77, A78, A79, A80, A81, A82, A83, A84, A85, A86, A87, A88, A89, A90, A91, A92, A93, A94, A95, A96, A97, A98, A99, A100.
- Ramps:** North Ramp, West Ramp, South Ramp, East Ramp, and Air Freight Ramp.
- Facilities:** FBO, U.S. Customs, Terminal, ATC, and various taxiways.
- Other Features:** Restricted Area, Non-Visibility Area, Fuel Tank Farm, Fire Station, Access Road, and various taxiways.
- Coordinates:** 32°08'N, 32°07'N, 32°06'N.
- Scale:** 1 inch = 100 feet.
- North Arrow:** VAR 9 2° E.
- Annual Rate of Change:** 0.1° W.

CAUTION: ENGINE TEST STANDS. DO NOT BLAST.
CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.
ALL AIRCRAFT USE UPPER ANTENNA UNTIL AIRBORNE

HIRL Rwy 12-30
MIRL Rwy 4-22
REIL Rwy 22 and 30

AIRPORT DIAGRAM

25275

TUCSON, ARIZONA
TUCSON INTL (TUS)

SW-4, 22 JAN 2026 to 19 FEB 2026