

AIRPORT DIAGRAM

BIRMINGHAM-SHUTTLESWORTH INTL (BHM)
AL-50 (FAA) BIRMINGHAM, ALABAMA

ATIS
119.4 270.1
BIRMINGHAM TOWER
119.9 317.725
GND CON
121.7 348.6
CLNC DEL
125.675 305.2




RWY 06-24
PCR 1102 F/D/X/T
S-120, D-250, 2D-485, 2D/2D2-992
RWY 18-36
PCR 440 F/D/X/T
S-105, D-143, 2D-197

VAR 3.9° W
JANUARY 2025
ANNUAL RATE OF CHANGE
0.1° W

FIELD
ELEV
650

SE-4, 16 APR 2026 to 14 MAY 2026



SE-4, 16 APR 2026 to 14 MAY 2026

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

86°46'W

86°45'W

AIRPORT DIAGRAM

BIRMINGHAM, ALABAMA
BIRMINGHAM-SHUTTLESWORTH INTL (BHM)