

AIRPORT DIAGRAM

BELLINGHAM INTL (BLI)
BELLINGHAM, WASHINGTON

AL-45 (FAA)

ATIS
134.45
BELLINGHAM TOWER ★
124.9 379.3
GND CON
127.4 379.3

D

ELEV
163

9L

B

164°

48°48.0'N

RWY 16-34
PCR 739 F/D/X/T
S-75, D-160, 2D-250

CARGO

COMMERCIAL
AIRCRAFT
PARKING

COMMERCIAL
TERMINAL
US
CUSTOMS

TWR

FBO/GENERAL AVIATION
TERMINAL

TRANSIENT
PARKING

GENERAL
AVIATION
HANGARS

FIRE
STATION

HANGAR

ATC NON-VISIBILITY AREAS

FIELD
ELEV
171

34

48°47.0'N

122°32.5'W

122°32.0'W

122°31.5'W

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
REDBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

NW-1, 14 MAY 2026 to 11 JUN 2026

NW-1, 14 MAY 2026 to 11 JUN 2026

AIRPORT DIAGRAM

BELLINGHAM, WASHINGTON
BELLINGHAM INTL (BLI)