


AIRPORT DIAGRAM

AL-180 (FAA)

GREENVILLE DOWNTOWN (GMU)
GREENVILLE, SOUTH CAROLINA

ATIS
127.075
GREENVILLE TOWER*
119.9 257.7
GND CON
121.25

D



JANUARY 2000
ANNUAL RATE OF CHANGE
0.1° W

HANGARS

HANGAR

TWR/BCN/
TERMINAL

EMAS

FIELD
ELEV
1048

HANGARS

HANGARS

EAST
RAMP

H2

G

A6

A7

A

B

B4

B

B3

B

G

A6

A6

B3

B

G

A5

A

G

A5

G

C

C

D

D

D6

C4

A

A

A3

B1

F

A

A2

A1

ELEV
989

34°51.0' N

34°50.5' N

ELEV
994

10

0.5% UP

D3

D

0.96°

D3

D

4000 X 80

C1

C2

D4

D

G

D

D

D

D

D

D

D

D

D

D

D

D

D

D

D

WEST
RAMP

SOUTH
RAMP

SOUTHEAST
RAMP

276°

28

28

5393 X 100

1.1% UP

ELEV
1015

RWY 01-19
PCN 23 F/C/X/T
S-61, D-81, 2D-151
RWY 10-28
PCN 16 F/C/Y/T
S-43.5, D-62
HELIPAD H1
S-20
HELIPAD H2
S-20

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

82°21.5' W

82°21.0' W

AIRPORT DIAGRAM

GREENVILLE, SOUTH CAROLINA
GREENVILLE DOWNTOWN (GMU)

SE-2, 14 MAY 2026 to 11 JUN 2026

SE-2, 14 MAY 2026 to 11 JUN 2026