

AIRPORT DIAGRAM


AL-282 (FAA)

NASHVILLE INTL (BNA)
NASHVILLE, TENNESSEE

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

SAID in use. Operate transponders with altitude reporting mode and ADS-B (if equipped) enabled on all airport surfaces.

D-ATIS 135.1
NASHVILLE TOWER 118.6 257.8
GND CON 121.9 348.6
CLNC DEL 126.05
CPDLC
PDC
D



SE-1, 14 MAY 2026 to 11 JUN 2026

SE-1, 14 MAY 2026 to 11 JUN 2026

AIRPORT DIAGRAM

NASHVILLE, TENNESSEE
NASHVILLE INTL (BNA)

86°41'W 86°40'W

JANUARY 2010 ANNUAL RATE OF CHANGE 0.1° W