

AIRPORT DIAGRAM

BIRMINGHAM-SHUTTLESWORTH INTL (BHM)
AL-50 (FAA)
BIRMINGHAM, ALABAMA

ATIS
119.4 270.1
BIRMINGHAM TOWER
119.9 317.725
GND CON
121.7 348.6
CLNC DEL
125.675 305.2


D

RWY 06-24
PCR 1102 F/D/X/T
S-120, D-250, 2D-485, 2D/2D2-992
RWY 18-36
PCR 440 F/D/X/T
S-105, D-143, 2D-197

33°35'N
33°34'N
33°33'N
JANUARY 2010
ANNUAL RATE OF CHANGE
0.1° W

SE-4, 09 JUL 2026 to 06 AUG 2026

SE-4, 09 JUL 2026 to 06 AUG 2026



CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READEBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

86°46'W

86°45'W

AIRPORT DIAGRAM

BIRMINGHAM, ALABAMA
BIRMINGHAM-SHUTTLESWORTH INTL (BHM)