


AIRPORT DIAGRAM

AL-5570 (FAA)

JACKSONVILLE INTL (JAX)
JACKSONVILLE, FLORIDA

D-ATIS
125.85
JACKSONVILLE TOWER
118.3 317.7
GND CON
121.9 348.6
CLNC DEL
119.5 290.275
CPDLC
PDC


SAID in use. Operate transponders with altitude reporting mode and ADS-B (if equipped) enabled on all airport surfaces.



JANUARY 2010
ANNUAL RATE OF CHANGE
0.1° W

SE-3. 09 JUL 2026 to 06 AUG 2026

SE-3. 09 JUL 2026 to 06 AUG 2026



RWY 08-26
PCR 970 R/A/W/T
S-120, D-250, 2D-550, 2D/2D2-1120
RWY 14-32
PCR 1380 R/B/W/T
S-120, D-250, 2D-550, 2D/2D2-1120

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

81°42'W

81°41'W