CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.
SAID in use. Operate transponders with altitude reporting mode and ADS-B (if equipped) enabled on all airport surfaces.
JANUARY 2020
ANNUAL RATE OF CHANGE
0.1° W
VAR 10° E
HS 1
10518 X 150
5501 X 75
3800 X 75
0.8% DOWN
1.9% UP
1.0% UP
1.3% UP
ELEV 3584
ELEV 3534
ELEV 3614
ELEV 3636
ELEV 3488
FIELD ELEV 3662
101°
254°
074°
281°
HIRL Rwy 10L-28R
MIRL Rwys 10R-28L and 7-25
REIL Rwys 28R and 25
ATIS 126.3
BILLINGS TOWER 127.2 257.8
GND CON 121.9
CLNC DEL 121.9
D
TERMINAL
TWR
FIRE STATION
EXECUTIVE HANGAR AREA
FBO
FBO
RWY 07-25
PCR 303 F/B/X/T
S-12.5
RWY 10L-28R
PCR 745 F/B/X/T
S-120, D-214, 2D-365
RWY 10R-28L
PCR 107 F/B/X/T
S-12.5
45°49'N
45°48'N
108°34'W
108°33'W
108°32'W
108°31'W