37°40.0'N
37°39.5'N
122°08.0'W
122°07.5'W
122°07.0'W
SAID in use. Operate transponders with altitude reporting mode and ADS-B (if equipped) enabled on all airport surfaces.
VAR 15° E
JANUARY 2005
ANNUAL RATE OF CHANGE
0.1° W
TERMINAL/AIRPORT ADMINISTRATION
TWR
FBO RAMP
GA TRANSIENT RAMP
WEST HANGARS
EAST HANGARS
FBO RAMP
FBO RAMP
FIRE STATION
ELEV 37
FIELD ELEV 52
HS 1
HS 2
HS 3
HS 4
HS 5
HS 5
10L
ELEV 28
105°
0.3% UP
10R
ELEV 28
105°
0.4% UP
3108 X 75
5694 X 150
285°
28R
28L
RUN-UP
285°
MIRL Rwy 10L-28R
MIRL Rwy 10R-28L
REIL Rwys 10R and 28L
RWY 10L-28R S-13
RWY 10R-28L S-30, D-75
CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.
ATIS 126.7
HAYWARD TOWER ★ 120.2 (CTAF) 257.8
GND CON 121.4
CLNC DEL 128.05