
ALASKA



DELTA DAVES (See DELTA JUNCTION on page 94)

DELTA JUNCTION

JULLIA JUNCTION ALL WEST (AK77) PVT 11 E UTC-9(-8DT) N63°56.49' W145°25.33' 1275 NOTAM FILE Not insp. RWY 09-27: 5500X75 (TURF-GRVL) AIRPORT REMARKS: Unattended. AIRPORT MANAGER: 907-895-9800 COMM/NAV/WEATHER REMARKS: For a toll free call to Fairbanks FSS dial 1-866-248-6516.	ANCHORAGE H-1B, L-1A, 3B, 3E
DELTA DAVES (AA22) PVT 7 NW UTC-9(-8DT) N64°07.97' W145°48.27' 1050 NOTAM FILE Not insp. RWY 15-33: 2350X60 (TURF) RWY 15: Trees. RWY 33: Rgt tfc. AIRPORT REMARKS: Unattended. AIRPORT REMARKS: Unattended. AIRPORT MANAGER: 907-895-4887 COMM/NAV/WEATHER REMARKS: For a toll free call to Fairbanks FSS dial 1–866–248–6516.	FAIRBANKS
DELTA JUNCTION (D66) 1 N UTC-9(-8DT) N64°03.01´W145°43.35´ 1150 NOTAM FILE FAI RWY 07-25: 2500X60 (GRVL) RWY 07: Trees.	FAIRBANKS
 RWY 25: Trees. Rgt tfc. AIRPORT REMARKS: Unattended. Rwy condition not monitored, recommend visual inspection of Allen Army arfld. Rwy 07 p-line W of rwy marked with orange balls. Clnc slope to p-of arpt. Arpt and electricity usage fees apply. Ctc arpt mgmt. Rwy 07–25 edges markee parking on East end, South side of Rwy 07. Personnel and eqpt may be working on the AIRPORT MANAGER: 907-460-6688 COMMUNICATIONS: CTA F122.9 SUAIS 125.3 126.3 (1-800-758-8723). COMM.NAV/WEATHER REMARKS: For a toll free call to Fairbanks FSS dial 1–866–248–6516. 	line 33:1. 335' lgtd twr 1 mi S with reflective cones. Transient