

## FRIENDLY

**POTOMAC AIRFIELD** (VKX)(KVKX) 0 NE UTC-5(-4DT) N38°44.92' W76°57.36'

118 B NOTAM FILE DCA

**RWY 06-24:** H2665X40 (ASPH) MIRL 0.3% up NE

**RWY 06:** REIL. PAPI(P2L)—GA 5.0° TCH 19'. Thld dspld 376'. Trees.

**RWY 24:** REIL. PAPI(P2L)—GA 5.5° TCH 20'. Thld dspld 90'. Trees.

**SERVICE:** S4 **FUEL** 100LL **LGT** MIRL Rwy 06-24 opr SS-SR; To ACTVT otr times and ACTVT PAPI Rwy 06 and 24—CTAF. Rwy 06 PAPI cntrln use only. Rotating bcn located 1000' north of arpt.

**NOISE:** Noise abatement procedures: avoid takeoff 0300-1200Z‡.

**AIRPORT REMARKS:** Attended 1200-0300Z‡. Expect 24 hr surveillance: civil and mil, ground and air. Arpt within Flt Rstrd Zone (FRZ). FRZ pilots must file FRZ scty FP thru 703-771-3476. SFRA or IFR FP does not grant FRZ asp aces. For aces pilot must be pre-apvd thru TSA MD3 program. To apply for FRZ access, see arpt website. Unlimited vehicle access to acft movement areas.

**AIRPORT MANAGER:** 301-248-5720

**COMMUNICATIONS:** CTAF/AUNICOM 122.8

® **POTOMAC APP/DEP CON** 124.7 125.65 (DC-FRZ)

**CLEARANCE DELIVERY PHONE:** For CD ctc Potomac Apch at 866-599-3874.

**RADIO AIDS TO NAVIGATION:** NOTAM FILE ADW.

**ANDREWS (L) (L) VORTACW** 113.1 ADW Chan 78 N38°48.43'  
W76°51.98' 240° 5.5 NM to fld. 263/10W.

VOR unusable:

035°-045° blo 2,500'

089°-182°

183°-227° blo 4,000'

230°-236° byd 20 NM

237°-270°

333°-048°

TACAN AZIMUTH unusable:

035°-045° blo 2,500'

220°-280°

295°-310°

DME unusable:

035°-045° blo 2,500'

220°-280°

**COMM/NAV/WEATHER REMARKS:** Automated UNICOM; 3 clicks adzy and wx, 4 clicks radio check. Visitors please tune 122.85 for parking instructions and gnd svcs.

WASHINGTON

COPTER

L-29E, 34F, 36I, A

IAP

