

MARSHALL ISLANDS

ARNO ATOLL

**INE** (N20) 0 NW UTC+12 N07°01.00' E171°29.00'  
4 NOTAM FILE HNL Not insp.  
**RWY 08-26:** 2450X50 (GRVL-CORAL)  
**AIRPORT REMARKS:** Attended on call.  
**COMMUNICATIONS:** CTAF 122.9

**TINAK** (N18) 0 N UTC+12 N07°08.00' E171°55.00'  
4 NOTAM FILE HNL Not insp.  
**RWY 05-23:** 2850X45 (GRVL-CORAL)  
**AIRPORT REMARKS:** Attended on call.  
**COMMUNICATIONS:** CTAF 122.9

ENEWETAK

**ENEWETAK AUX AF** (PKMA) (AF) UTC+12 N11°20.45' E162°19.67' P-18  
13 AOE Not insp.  
**RWY 06-24:** H7700X148 (ASPH) D-106, 2S-134, 2D-170, C5-575  
**AIRPORT REMARKS:** Opr Mon-Sat 2000-0500Z, Enewetak date. Official business only, PPR. Multi unlighted twr up to 100' in vicinity rwy. Rwy badly deteriorated, emergency ldg only. IFR acft arr Enewetak remain in ctc with Hickam till cleared to Enewetak Radio. Request 2 hour eta notice. No com watch on radio freq outside normal hour of opr. Arr acft trans in blind on 121.5 acft call sign, ETA-100 NM from station. 2 trans, 3 min intervals, IFR dep clnc fr Hickam.  
**COMM/NAV/WEATHER REMARKS:** Trml advisory svc.

JABOR JALUIT ATOLL

**JALUIT** (N55) 1 SE UTC+12 N05°54.40' E169°38.50'  
4 NOTAM FILE HNL Not insp.  
**RWY 03-21:** 5000X60 (GRVL-CORAL)  
**SERVICE:** FUEL 100  
**AIRPORT REMARKS:** Attended on call. Fuel used for local operations only. For refueling contact Air Marshall Islands (692) 93731.  
**COMMUNICATIONS:** CTAF 122.9

KILI ISLAND

**KILI** (C51) 0 N UTC+12 N05°39.00' E169°07.00'  
5 NOTAM FILE HNL Not insp.  
**RWY 04-22:** 4400X100 (GRVL-CORAL)  
**AIRPORT REMARKS:** Attended on call.  
**COMMUNICATIONS:** CTAF 122.9