AIRPORT DIAGRAM
24361

AIRPORT DIAGRAM
24361

DANIEL K INOUYE INTL (HNL) (PHNL)
HONOLULU, HI

DANIEL K INOUYE INTL (HNL) (PHNL)
HONOLULU, HI

AL-754 (FAA)

D-ATIS
127.9 251.15
HONOLULU TOWER
118.1 257.8
123.9 273.575 (RWY 08R-26L)
GND CON
121.9 348.6
GND CON (RAMP CON)
121.8
CLNC DEL
121.4 281.4
PDC
D

157°57'W 157°56'W 157°55'W

21°20'N

21°19'N

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

ASDE-X in use. Operate transponders with altitude reporting mode and ADS-B (if equipped) enabled on all surfaces.

JOINT BASE PEARL HARBOR-HICKAM

BASE OPS

HICKAM RAMP ADVISORY

TERMINAL

AIR FREIGHT

FIRE STATION

TRAN ALERT

HAWAII ANG

FIELD ELEV 14

ATC NON-VISIBILITY AREA

HAZARDOUS CARGO PAD

TWR 190

ELEV 10

BAK-14

LAHSO

HS 1

HS 2

HS 3

HS 4

080.5°

260.5°

043.5°

041.5°

081.5°

261.5°

12360 X 200

9002 X 150

6952 X 150

5090 X 300

3000 X 150

12000 X 200

ELEV 8

ELEV 9

ELEV 0

GENERAL AVIATION CARGO

CALIBRATION PAD

FIRE STATION

BCN

VAR 9.5° E

JANUARY 2020
ANNUAL RATE OF CHANGE
0.0° E

HIRL Rwys 4R-22L, 8L-26R and 8R-26L
MIRL Rwy 4L-22R
REIL Rwys 22L, 26R, 4L, 22R and 8R

RWY 04L-22R
PCR 740 F/B/X/T
S-120, D-250, 2D-550,
2D/2D2-1100

RWY 04R-22L
PCR 430 F/A/X/T
S-111, D-194, 2D-361,
2D/2D2-762

RWY 08L-26R
PCR 620 R/B/W/T
S-120, D-198, 2D-341,
2D/2D2-801

RWY 08R-26L
PCR 852 F/A/X/T
S-120, D-250, 2D-550,
2D/2D2-1120