D-ATIS ARR 123.775
DEP 135.925
DFW TOWER
124.15 134.9 (WEST)
126.55 127.5 (EAST)
GND CON
121.65 121.8 (EAST)
121.85 (WEST)
CLNC DEL
128.25
CPDLC
PDC
D
ASDE-X in use. Operate transponders with altitude reporting mode and ADS-B (if equipped) enabled on all airport surfaces.
Runway Status Lights in operation.
JANUARY 2025
ANNUAL RATE OF CHANGE
0.1° W
VAR 2.8° E
FIELD ELEV 606
CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.
RWY 13L-31R
PCR 1870 R/B/W/T
S-120, D-250, 2D-550, 2D/2D2-1120
RWY 13R-31L
PCR 1220 R/B/W/T
S-120, D-250, 2D-485, 2D/2D2-1005
RWY 17C-35C
PCR 2080 R/B/W/T
S-120, D-250, 2D-550, 2D/2D2-1120
RWY 17L-35R
PCR 1730 R/B/W/T
S-120, D-250, 2D-550, 2D/2D2-1120
RWY 17R-35L
PCR 1620 R/B/W/T
S-120, D-250, 2D-550, 2D/2D2-1049
RWY 18L-36R
PCR 1130 R/B/W/T
S-120, D-250, 2D-550, 2D/2D2-1066
RWY 18R-36L
PCR 1540 R/B/W/T
S-120, D-250, 2D-490, 2D/2D2-985
HIRL all rwys
REIL Rwys 13L and 31L
TDZL/RCLS all rwys except 13L and 31L
9300 X 150
9000 X 200
13400 X 150
13400 X 200
13401 X 200
8500 X 150
177.5°
357.5°
177.4°
357.4°
0.6% UP
0.6% DOWN
0.5% UP
0.5% DOWN
312.5°
132.5°
136.2°
316.3°
ELEV 508
ELEV 524
ELEV 576
ELEV 362
ELEV 553
ELEV 567
ELEV 563
ELEV 602
ELEV 575
ELEV 591
ELEV 582
ELEV 577
EAST AIR FREIGHT
FIRE STATION #3
RWY 17L APCH HOLD
EAST TWR
LAHSO
LAHSO HANGAR 5
FIRE STATION #1
ILS HOLD
NE HOLD PAD
1E CORPORATE AVIATION RAMP
NW HOLD PAD
CENTER TWR
U.S. CUSTOMS
CENTRAL TERMINAL AREA
SE HOLD PAD
5E SOUTH AIR FREIGHT RAMP
DE-ICING AREA
FIRE STATION #5
NORTH WEST AIR FREIGHT
FIRE STATION #2
WEST AIR FREIGHT
HANGARS
WEST TWR
WEST CARGO
FIRE STATION #4
ILS HOLD
97°04'W
97°03'W
97°02'W
97°01'W
97°00'W
32°55'N
32°54'N
32°53'N