ILS or LOC RWY 36
ST PETE-CLEARWATER INTL (PIE)

LOC/DME I-CWT 108.7 Chan 24	APP CRS 356°	Rwy Ldg 8720 TDZE 10 Apt Elev 11

DME or RADAR required.

MISSED APPROACH: Climb to 600 then climbing left turn to 2000 on PIE VORTAC R-276 to LAFAL INT/PIE 8 DME and hold.

ATIS	TAMPA APP CON	ST PETERSBURG-CLEARWATER TOWER★	GND CON	UNICOM
134.5	125.3 316.05	118.3 (CTAF) L 257.8	121.9 348.6	122.95



ELEV 11 | D | TDZE 10

TDZL/RCLS Rwy 18 L
HIRL Rwy 18-36 L
MIRL Rwy 4-22 L
REIL Rwys 4 and 22



FAF to MAP 6.1 NM

Knots	60	90	120	150	180
Min:Sec	6:06	4:04	3:03	2:26	2:02

SAWGA FIX MINIMUMS DME required.



CATEGORY	A	B	C	D	E
S-ILS 36	210/40 200 (200-¾)				
S-LOC 36	680/55 670 (700-1)		680-1⅞ 670 (700-1⅞)		
CIRCLING	680-1 669 (700-1)		680-1½ 669 (700-1½)	680-2 669 (700-2)	960-3 949 (1000-3)
SAWGA FIX MINIMUMS					
S-LOC 36	380/55 370 (400-1)				
CIRCLING	520-1 509 (600-1)		640-1½ 629 (700-1½)	680-2 669 (700-2)	960-3 949 (1000-3)

SE-3, 14 MAY 2026 to 11 JUN 2026